INSTALLATION AND TECHNICAL INFORMATION

PLEASE READ AND FOLLOW ALL SAFETY INSTRUCTIONS

SAVE THIS SHEET

To Avoid Risk of Electric Shock and Injury

- Never attempt any work on the luminaire unless it is disconnected from the power source.
- Any Installation and service of the luminaire should be done by a certified electrician.
- Confirm the supply voltage matches the voltage labeled on the luminaire.
- Make sure all electrical and grounded connections are in accordance with the National Electric Code (NEC) and any local codes.
- Make sure all connections are capped with UL-listed wire connectors.
- Allow luminaire to cool down before handling. Never handle luminaire when it is in use.
- Do not exceed the maximum wattage labeled on luminaire.
- · Always wear gloves and safety glasses when installing, handling, or performing routine maintenance on the luminaire.
- Do not look directly at the light source when luminaire is on.

To Avoid Risk of Fire and Product Damage

- Keep any combustible material away from the luminaire.
- Do not operate luminaire near any persons, materials, or substances that are sensitive to heat.
- · When mounting, make sure wiring is secured from any edges or objects that can damage the wire insulation.
- Do not obstruct ventilation of the luminaire. Do not cover the luminaire with foam or other insulation material that will restrict convection or conduction cooling.
- Only use luminaire at its intended location.
- LED fixtures are sensitive to polarity. Make sure to identify proper polarity before installing.
- Electrostatic Discharge (or ESD) can damage LED luminaire. Make sure to always wear personal grounding equipment when installing or servicing the luminaire.
- · Avoid touching individual electrical components, which can cause ESD and will reduce the life and performance of the luminaire.
- Do not power luminaire on and off frequently as this will greatly reduce luminaire's lifespan.
- Always read the luminaire's complete installation instruction sheet before installing luminaire.
- Always inspect the luminaire for damage. DO NOT INSTALL fixture if there is any damage. Contact your distributor or representative where you
 purchased the luminaire for warranty claim if luminaire is damaged.

To Maintain Luminaire and Ensure Consistent Performance

- IMPORTANT: Always make sure luminaire is disconnected from power source when performing routine maintenance.
- Occasionally clean luminaire lens. When cleaning lens, you may dust with soft, dry and clean cloth. You may also use solution of warm water and non-abrasive cleaning agent then wipe with dry cloth. DO NOT USE alkaline or acid cleaners.
- · Keep heatsink clear of dust or debris from time to time.
- Maintaining the luminaire on a routine basis is highly recommended.

Failure to follow any of these instructions may void warranty.

Please visit www.alslighting.us to view complete product Terms and Conditions.

Advantage Lighting Solutions assumes no responsibility for claims arising from improper or careless installation or handling of its products.

Important Safety Instructions

- 1. Make sure power is turned OFF before installing.
- 2. Inspect fixture for any damages. If damaged, DO NOT install fixtureand contact local ALS distributor immediately.




INSTALLATION AND TECHNICAL INFORMATION

Installation Instructions

Mounting With Steel Aircraft Cable Kit


- 1. Each of the two steel aircraft cable hooks on both ends of the mounting holes on fixture.
- 2. Remove the access plate, take the wires out of the power driver.
- 3. Compartment and through the hole of access plate, make wiring and re-install the access plate, then plug the flexible conduit into the hole of the access plate.



Installation Instructions

Mounting With Conduit Pipe


- 1. Installing the adjustable board in square J-BOX with M4*8 y-headed at bottom screw, and pass the 3/4" conduit through adjustable board, then fixx it with J-BOX. (nut is provided by others)
- 2. Attach fixture to the hanger of square J-BOX, and connecting wires.
- 3. Placing fixture horizontally, and fix it with J-BOX by using M5*8 screws.



Installation Instructions

Surface Mount


- 1. Fix the square J-BOX hanger to the ceiling junction box with screws (the screws are matched with the junction box).
- 2. Hook the fixture of the J-BOX base to the fixed hanger, pull out the wire and complete the wiring
- 3. Place the fixture horizontally and secure it with M5 * 8 screws.



Wiring Diagram

Universal voltage driver permits operation at 120V thru 277V, 60 Hz. For 0-10V Dimming, follow the wiring directions.

- 1. Connect the black fixture lead to the (+) LINE supply lead.
- 2. Connect the white fixture lead to the (-) COMMON supplylead.
- 3. Connect the GROUND wire from fixture to supply ground. Do NOT connect the GROUND of the dimming fixture to the output.
- 4. Connect the purple fixture lead to the (V+) DIM lead.
- 5. Connect the gray fixture lead to the (V-) DIM lead.





INSTALLATION AND TECHNICAL INFORMATION

Cleaning & Maintenance

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

Troubleshooting

- 1. Check that the line voltage at the fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly?
- 3. Be sure the motion sensor, if used, is functioning properly.